

# METAR Lightbox

Real-time aviation weather display



## FIRST-TIME SETUP

### 1 Power on

Plug in the micro-USB cable. The light will animate, then pulse blue indicating setup mode is active.

*No blue pulse after 60 sec? Press & hold the blue button for 5 seconds.*

### 2 Join setup network

On your phone or computer, connect to Wi-Fi: METAR-LIGHTBOX-SETUP

### 3 Open the setup page

A page should open automatically. If not, visit: <http://10.42.0.1>

### 4 Enter your details

Your home Wi-Fi name & password (2.4 GHz only)  
Your airport's ICAO code e.g. KJFK, KSFO, KBOS

### 5 Save & wait


Tap Save & Apply. The device reboots and joins your network in about 30 seconds.

## AFTER SETUP

Access the full portal from any device on your home network:

<http://metar-lightbox.local/>

## FLIGHT CATEGORY COLORS

-  **Green** VFR — Clear conditions
-  **Blue** MVFR — Marginal VFR
-  **Red** IFR — Instrument conditions
-  **Magenta** LIFR — Low instrument conditions
-  **Magenta (flash)** Thunderstorm / hazard
-  **White flash** Wind gust alert (>10 kt above sustained)